SD Memory Card Compatibility Information for Sony® Digital Camcorders

Important Information:

- This "Compatibility Chart" only provides compatibility testing results for the Memory Card applications listed in each product’s instruction manual with Memory Stick media types listed below.
- This chart does not guarantee support for all memory card media types' performance nor compatibility among memory card media compliant products.
- Attach a dedicated adapter to use microSD/microSDHC memory card in a slot for standard size SD/SDHC memory card.
- The Memory Stick media capacity indicated on the packaging will differ from actual usable capacity. A portion of the memory is used for data management file functions.
- This compatibility chart and specifications are subject to change without notice.

Notes:

46	The SRAC-A1 adapter must be attached to use microSD/microSDHC in a slot for SD/SDHC media.
47	This SD Card may not be able to record or play video.
50	This media cannot be used as file system is different.
51	Not support the high speed data transfer for UHS-I.
53	This media is not compatible with XAVC S movie mode.

	SD Memory Card											
Camcorder	**SF-128UY**	**SF-16BF**	**SF-16C4**	**SF-16N4**	**SF-16NX**	**SF-16U4**	**SF-16U6**	**SF-16UX**	**SF-16UY**	**SF-2B4**	**SF-2C1**	**SF-2N1**
FDR-AX100	-	OK *53	OK *53	OK *53	OK *53	OK *53	OK *53	OK	OK *53	OK *53	OK *53	OK *53
HDR-CX240	-	-	-	-	-	-	-	-	-	-	-	-
HDR-CX330	-	-	-	-	-	-	-	-	-	-	-	-
HDR-CX900	-	OK *53	OK *53	OK *53	OK *53	OK *53	OK *53	OK	OK *53	OK *53	OK *53	OK *53
HDR-PJ275	-	-	-	-	-	-	-	-	-	-	-	-
HDR-PJ340	-	-	-	-	-	-	-	-	-	-	-	-
HDR-PJ350	-	-	-	-	-	-	-	-	-	-	-	-
HDR-PJ540	-	-	-	-	-	-	-	-	-	-	-	-
HDR-PJ810	-	OK	OK	OK	OK	OK	OK	OK	OK	OK	OK	OK
HDR-CX220	-	-	OK	OK	OK	OK	OK	OK	OK	OK	OK	OK
HDR-CX230	-	-	OK	OK	OK	OK	OK	OK	OK	OK	OK	OK
HDR-CX290	-	-	OK	OK	OK	OK	OK	OK	OK	OK	OK	OK
HDR-CX380	-	-	OK	OK	OK	OK	OK	OK	OK	OK	OK	OK
HDR-CX430V	-	-	OK	OK	OK	OK	OK	OK	OK	OK	OK	OK
HDR-PJ230	-	-	OK	OK	OK	OK	OK	OK	OK	OK	OK	OK
HDR-PJ380	-	-	OK	OK	OK	OK	OK	OK	OK	OK	OK	OK

	SD Memory Card											
Camcorder	**SF-128UY**	**SF-16BF**	**SF-16C4**	**SF-16N4**	**SF-16NX**	**SF-16U4**	**SF-16U6**	**SF-16UX**	**SF-16UY**	**SF-2B4**	**SF-2C1**	**SF-2N1**
HDR-PJ430V	-	-	OK	OK	OK	OK	OK	OK	OK	OK	OK	OK
HDR-PJ650V	-	-	OK	OK	OK	OK	OK	OK	OK	OK	OK	OK
HDR-PJ790V	-	-	OK	OK	OK	OK	OK	OK	OK	OK	OK	OK
HDR-TD30V	-	-	OK	OK	OK	OK	OK	OK	OK	OK	OK	OK
HDR-CX190	-	-	OK	OK	OK	OK	OK	OK	OK	OK	OK	OK
HDR-CX200	-	-	OK	OK	OK	OK	OK	OK	OK	OK	OK	OK
HDR-CX210	-	-	OK	OK	OK	OK	OK	OK	OK	OK	OK	OK
HDR-CX260V	-	-	OK	OK	OK	OK	OK	OK	OK	OK	OK	OK
HDR-CX580V	-	-	OK	OK	OK	OK	OK	OK	OK	OK	OK	OK
HDR-CX760V	-	-	OK	OK	OK	OK	OK	OK	OK	OK	OK	OK
HDR-GW77V	-	-	-	-	-	-	-	-	-	-	-	-
HDR-PJ200	-	-	OK	OK	OK	OK	OK	OK	OK	OK	OK	OK
HDR-PJ260V	-	-	OK	OK	OK	OK	OK	OK	OK	OK	OK	OK
HDR-PJ580V	-	-	OK	OK	OK	OK	OK	OK	OK	OK	OK	OK
HDR-PJ710V	-	-	OK	OK	OK	OK	OK	OK	OK	OK	OK	OK
HDR-PJ760V	-	-	OK	OK	OK	OK	OK	OK	OK	OK	OK	OK
HDR-TD20V	-	-	OK	OK	OK	OK	OK	OK	OK	OK	OK	OK

	SD Memory Card											
Camcorder	**SF-128UY**	**SF-16BF**	**SF-16C4**	**SF-16N4**	**SF-16NX**	**SF-16U4**	**SF-16U6**	**SF-16UX**	**SF-16UY**	**SF-2B4**	**SF-2C1**	**SF-2N1**
HDR-XR260V	-	-	OK	OK	OK	OK	OK	OK	OK	OK	OK	OK
DCR-SX45	-	-	OK	OK	OK	OK	OK	OK	OK	OK	OK	OK
DCR-SX65	-	-	OK	OK	OK	OK	OK	OK	OK	OK	OK	OK
DCR-SX85	-	-	OK	OK	OK	OK	OK	OK	OK	OK	OK	OK
HDR-CX130	-	-	OK	OK	OK	OK	OK	OK	OK	OK	OK	OK
HDR-CX160	-	-	OK	OK	OK	OK	OK	OK	OK	OK	OK	OK
HDR-CX360V	-	-	OK	OK	OK	OK	OK	OK	OK	OK	OK	OK
HDR-CX560V	-	-	OK	OK	OK	OK	OK	OK	OK	OK	OK	OK
HDR-CX700V	-	-	OK	OK	OK	OK	OK	OK	OK	OK	OK	OK
HDR-PJ10	-	-	OK	OK	OK	OK	OK	OK	OK	OK	OK	OK
HDR-PJ30V	-	-	OK	OK	OK	OK	OK	OK	OK	OK	OK	OK
HDR-PJ50V	-	-	OK	OK	OK	OK	OK	OK	OK	OK	OK	OK
HDR-TD10	-	-	OK	OK	OK	OK	OK	OK	OK	OK	OK	OK
HDR-XR160	-	-	OK	OK	OK	OK	OK	OK	OK	OK	OK	OK
DCR-SR68	-	-	OK	OK	OK	OK	OK	OK	OK	OK	OK	OK
DCR-SR88	-	-	OK	OK	OK	OK	OK	OK	OK	OK	OK	OK
DCR-SX43	-	-	OK	OK	OK	OK	OK	OK	OK	OK	OK	OK

	SD Memory Card											
Camcorder	**SF-128UY**	**SF-16BF**	**SF-16C4**	**SF-16N4**	**SF-16NX**	**SF-16U4**	**SF-16U6**	**SF-16UX**	**SF-16UY**	**SF-2B4**	**SF-2C1**	**SF-2N1**
DCR-SX44	-	-	OK	OK	OK	OK	OK	OK	OK	OK	OK	OK
DCR-SX63	-	-	OK	OK	OK	OK	OK	OK	OK	OK	OK	OK
DCR-SX83	-	-	OK	OK	OK	OK	OK	OK	OK	OK	OK	OK
HDR-AX2000	-	-	OK	OK	OK	OK	OK	OK	OK	OK	OK	OK
HDR-CX110	-	-	OK	OK	OK	OK	OK	OK	OK	OK	OK	OK
HDR-CX150	-	-	OK	OK	OK	OK	OK	OK	OK	OK	OK	OK
HDR-CX300	-	-	OK	OK	OK	OK	OK	OK	OK	OK	OK	OK
HDR-CX350V	-	-	OK	OK	OK	OK	OK	OK	OK	OK	OK	OK
HDR-CX550V	-	-	OK	OK	OK	OK	OK	OK	OK	OK	OK	OK
HDR-XR150	-	-	OK	OK	OK	OK	OK	OK	OK	OK	OK	OK
HDR-XR350V	-	-	OK	OK	OK	OK	OK	OK	OK	OK	OK	OK
HDR-XR550V	-	-	OK	OK	OK	OK	OK	OK	OK	OK	OK	OK
NEX-VG30	-	-	OK	OK	OK	OK	OK	OK	OK	OK	OK	OK
NEX-VG30H	-	-	OK	OK	OK	OK	OK	OK	OK	OK	OK	OK
NEX-VG900	-	-	OK	OK	OK	OK	OK	OK	OK	OK	OK	OK
NEX-VG20	-	-	OK	OK	OK	OK	OK	OK	OK	OK	OK	OK
NEX-VG20H	-	-	OK	OK	OK	OK	OK	OK	OK	OK	OK	OK

	SD Memory Card											
Camcorder	**SF-128UY**	**SF-16BF**	**SF-16C4**	**SF-16N4**	**SF-16NX**	**SF-16U4**	**SF-16U6**	**SF-16UX**	**SF-16UY**	**SF-2B4**	**SF-2C1**	**SF-2N1**
NEX-VG10	-	-	OK	OK	OK	OK	OK	OK	OK	OK	OK	OK
HDR-AS20	-	-	-	-	-	-	-	-	-	-	-	-
HDR-AS100V	-	-	-	-	-	-	-	-	-	-	-	-
HDR-AS100VB	-	-	-	-	-	-	-	-	-	-	-	-
HDR-AS100VR	-	-	-	-	-	-	-	-	-	-	-	-
HDR-AS100VW	-	-	-	-	-	-	-	-	-	-	-	-
HDR-AS30V	-	-	-	-	-	-	-	-	-	-	-	-
HDR-AS30VB	-	-	-	-	-	-	-	-	-	-	-	-
HDR-AS30VD	-	-	-	-	-	-	-	-	-	-	-	-
HDR-AS30VR	-	-	-	-	-	-	-	-	-	-	-	-
HDR-AS30VW	-	-	-	-	-	-	-	-	-	-	-	-

	SD Memory Card											
Camcorder	**SF-2N1T**	**SF-32BF**	**SF-32C4**	**SF-32N4**	**SF-32NX**	**SF-32U4**	**SF-32U6**	**SF-32UX**	**SF-32UX2**	**SF-32UY**	**SF-32UZ**	**SF-4B4**
FDR-AX100	OK *53	OK *53	OK *53	OK *53	OK *53	OK *53	OK *53	OK	-	OK *53	-	OK *53
HDR-CX240	-	-	-	-	-	-	-	-	-	-	-	-
HDR-CX330	-	-	-	-	-	-	-	-	-	-	-	-
HDR-CX900	OK *53	OK *53	OK *53	OK *53	OK *53	OK *53	OK *53	OK	-	OK *53	-	OK *53
HDR-PJ275	-	-	-	-	-	-	-	-	-	-	-	-
HDR-PJ340	-	-	-	-	-	-	-	-	-	-	-	-
HDR-PJ350	-	-	-	-	-	-	-	-	-	-	-	-
HDR-PJ540	-	-	-	-	-	-	-	-	-	-	-	-
HDR-PJ810	OK	OK	OK	OK	OK	OK	OK	OK	-	OK	-	OK
HDR-CX220	OK	-	OK	OK	OK	OK	OK	OK	-	OK	-	OK
HDR-CX230	OK	-	OK	OK	OK	OK	OK	OK	-	OK	-	OK
HDR-CX290	OK	-	OK	OK	OK	OK	OK	OK	-	OK	-	OK
HDR-CX380	OK	-	OK	OK	OK	OK	OK	OK	-	OK	-	OK
HDR-CX430V	OK	-	OK	OK	OK	OK	OK	OK	-	OK	-	OK
HDR-PJ230	OK	-	OK	OK	OK	OK	OK	OK	-	OK	-	OK
HDR-PJ380	OK	-	OK	OK	OK	OK	OK	OK	-	OK	-	OK

	SD Memory Card											
Camcorder	**SF-2N1T**	**SF-32BF**	**SF-32C4**	**SF-32N4**	**SF-32NX**	**SF-32U4**	**SF-32U6**	**SF-32UX**	**SF-32UX2**	**SF-32UY**	**SF-32UZ**	**SF-4B4**
HDR-PJ430V	OK	-	OK	OK	OK	OK	OK	OK	-	OK	-	OK
HDR-PJ650V	OK	-	OK	OK	OK	OK	OK	OK	-	OK	-	OK
HDR-PJ790V	OK	-	OK	OK	OK	OK	OK	OK	-	OK	-	OK
HDR-TD30V	OK	-	OK	OK	OK	OK	OK	OK	-	OK	-	OK
HDR-CX190	OK	-	OK	OK	OK	OK	OK	OK	-	OK	-	OK
HDR-CX200	OK	-	OK	OK	OK	OK	OK	OK	-	OK	-	OK
HDR-CX210	OK	-	OK	OK	OK	OK	OK	OK	-	OK	-	OK
HDR-CX260V	OK	-	OK	OK	OK	OK	OK	OK	-	OK	-	OK
HDR-CX580V	OK	-	OK	OK	OK	OK	OK	OK	-	OK	-	OK
HDR-CX760V	OK	-	OK	OK	OK	OK	OK	OK	-	OK	-	OK
HDR-GW77V	-	-	-	-	-	-	-	-	-	-	-	-
HDR-PJ200	OK	-	OK	OK	OK	OK	OK	OK	-	OK	-	OK
HDR-PJ260V	OK	-	OK	OK	OK	OK	OK	OK	-	OK	-	OK
HDR-PJ580V	OK	-	OK	OK	OK	OK	OK	OK	-	OK	-	OK
HDR-PJ710V	OK	-	OK	OK	OK	OK	OK	OK	-	OK	-	OK
HDR-PJ760V	OK	-	OK	OK	OK	OK	OK	OK	-	OK	-	OK
HDR-TD20V	OK	-	OK	OK	OK	OK	OK	OK	-	OK	-	OK

	SD Memory Card											
Camcorder	**SF-2N1T**	**SF-32BF**	**SF-32C4**	**SF-32N4**	**SF-32NX**	**SF-32U4**	**SF-32U6**	**SF-32UX**	**SF-32UX2**	**SF-32UY**	**SF-32UZ**	**SF-4B4**
HDR-XR260V	OK	-	OK	OK	OK	OK	OK	OK	-	OK	-	OK
DCR-SX45	OK	-	OK	OK	OK	OK	OK	OK	-	OK	-	OK
DCR-SX65	OK	-	OK	OK	OK	OK	OK	OK	-	OK	-	OK
DCR-SX85	OK	-	OK	OK	OK	OK	OK	OK	-	OK	-	OK
HDR-CX130	OK	-	OK	OK	OK	OK	OK	OK	-	OK	-	OK
HDR-CX160	OK	-	OK	OK	OK	OK	OK	OK	-	OK	-	OK
HDR-CX360V	OK	-	OK	OK	OK	OK	OK	OK	-	OK	-	OK
HDR-CX560V	OK	-	OK	OK	OK	OK	OK	OK	-	OK	-	OK
HDR-CX700V	OK	-	OK	OK	OK	OK	OK	OK	-	OK	-	OK
HDR-PJ10	OK	-	OK	OK	OK	OK	OK	OK	-	OK	-	OK
HDR-PJ30V	OK	-	OK	OK	OK	OK	OK	OK	-	OK	-	OK
HDR-PJ50V	OK	-	OK	OK	OK	OK	OK	OK	-	OK	-	OK
HDR-TD10	OK	-	OK	OK	OK	OK	OK	OK	-	OK	-	OK
HDR-XR160	OK	-	OK	OK	OK	OK	OK	OK	-	OK	-	OK
DCR-SR68	OK	-	OK	OK	OK	OK	OK	OK	-	OK	-	OK
DCR-SR88	OK	-	OK	OK	OK	OK	OK	OK	-	OK	-	OK
DCR-SX43	OK	-	OK	OK	OK	OK	OK	OK	-	OK	-	OK

	SD Memory Card											
Camcorder	**SF-2N1T**	**SF-32BF**	**SF-32C4**	**SF-32N4**	**SF-32NX**	**SF-32U4**	**SF-32U6**	**SF-32UX**	**SF-32UX2**	**SF-32UY**	**SF-32UZ**	**SF-4B4**
DCR-SX44	OK	-	OK	OK	OK	OK	OK	OK	-	OK	-	OK
DCR-SX63	OK	-	OK	OK	OK	OK	OK	OK	-	OK	-	OK
DCR-SX83	OK	-	OK	OK	OK	OK	OK	OK	-	OK	-	OK
HDR-AX2000	OK	-	OK	OK	OK	OK	OK	OK	-	OK	-	OK
HDR-CX110	OK	-	OK	OK	OK	OK	OK	OK	-	OK	-	OK
HDR-CX150	OK	-	OK	OK	OK	OK	OK	OK	-	OK	-	OK
HDR-CX300	OK	-	OK	OK	OK	OK	OK	OK	-	OK	-	OK
HDR-CX350V	OK	-	OK	OK	OK	OK	OK	OK	-	OK	-	OK
HDR-CX550V	OK	-	OK	OK	OK	OK	OK	OK	-	OK	-	OK
HDR-XR150	OK	-	OK	OK	OK	OK	OK	OK	-	OK	-	OK
HDR-XR350V	OK	-	OK	OK	OK	OK	OK	OK	-	OK	-	OK
HDR-XR550V	OK	-	OK	OK	OK	OK	OK	OK	-	OK	-	OK
NEX-VG30	OK	-	OK	OK	OK	OK	OK	OK	-	OK	-	OK
NEX-VG30H	OK	-	OK	OK	OK	OK	OK	OK	-	OK	-	OK
NEX-VG900	OK	-	OK	OK	OK	OK	OK	OK	-	OK	-	OK
NEX-VG20	OK	-	OK	OK	OK	OK	OK	OK	-	OK	-	OK
NEX-VG20H	OK	-	OK	OK	OK	OK	OK	OK	-	OK	-	OK

	SD Memory Card											
Camcorder	**SF-2N1T**	**SF-32BF**	**SF-32C4**	**SF-32N4**	**SF-32NX**	**SF-32U4**	**SF-32U6**	**SF-32UX**	**SF-32UX2**	**SF-32UY**	**SF-32UZ**	**SF-4B4**
NEX-VG10	OK	-	OK	OK	OK	OK	OK	OK	-	OK	-	OK
HDR-AS20	-	-	-	-	-	-	-	-	-	-	-	-
HDR-AS100V	-	-	-	-	-	-	-	-	-	-	-	-
HDR-AS100VB	-	-	-	-	-	-	-	-	-	-	-	-
HDR-AS100VR	-	-	-	-	-	-	-	-	-	-	-	-
HDR-AS100VW	-	-	-	-	-	-	-	-	-	-	-	-
HDR-AS30V	-	-	-	-	-	-	-	-	-	-	-	-
HDR-AS30VB	-	-	-	-	-	-	-	-	-	-	-	-
HDR-AS30VD	-	-	-	-	-	-	-	-	-	-	-	-
HDR-AS30VR	-	-	-	-	-	-	-	-	-	-	-	-
HDR-AS30VW	-	-	-	-	-	-	-	-	-	-	-	-

	SD Memory Card											
Camcorder	**SF-4BF**	**SF-4C4**	**SF-4N4**	**SF-4N4D**	**SF-4U4**	**SF-4U6**	**SF-64BF**	**SF-64C4**	**SF-64N4**	**SF-64UX**	**SF-64UX2**	**SF-64UY**
FDR-AX100	OK *53	OK *53	OK *53	OK *53	OK *53	OK *53	OK *53	OK *53	OK *53	OK	-	OK *53
HDR-CX240	-	-	-	-	-	-	-	-	-	-	-	-
HDR-CX330	-	-	-	-	-	-	-	-	-	-	-	-
HDR-CX900	OK *53	OK *53	OK *53	OK *53	OK *53	OK *53	OK *53	OK *53	OK *53	OK	-	OK *53
HDR-PJ275	-	-	-	-	-	-	-	-	-	-	-	-
HDR-PJ340	-	-	-	-	-	-	-	-	-	-	-	-
HDR-PJ350	-	-	-	-	-	-	-	-	-	-	-	-
HDR-PJ540	-	-	-	-	-	-	-	-	-	-	-	-
HDR-PJ810	OK	OK	OK	OK	OK	OK	OK	OK	OK	OK	-	OK
HDR-CX220	-	OK	OK	OK	OK	OK	-	-	-	OK	-	-
HDR-CX230	-	OK	OK	OK	OK	OK	-	-	-	OK	-	-
HDR-CX290	-	OK	OK	OK	OK	OK	-	-	-	OK	-	-
HDR-CX380	-	OK	OK	OK	OK	OK	-	-	-	OK	-	-
HDR-CX430V	-	OK	OK	OK	OK	OK	-	-	-	OK	-	-
HDR-PJ230	-	OK	OK	OK	OK	OK	-	-	-	OK	-	-
HDR-PJ380	-	OK	OK	OK	OK	OK	-	-	-	OK	-	-

	SD Memory Card											
Camcorder	**SF-4BF**	**SF-4C4**	**SF-4N4**	**SF-4N4D**	**SF-4U4**	**SF-4U6**	**SF-64BF**	**SF-64C4**	**SF-64N4**	**SF-64UX**	**SF-64UX2**	**SF-64UY**
HDR-PJ430V	-	OK	OK	OK	OK	OK	-	-	-	OK	-	-
HDR-PJ650V	-	OK	OK	OK	OK	OK	-	-	-	OK	-	-
HDR-PJ790V	-	OK	OK	OK	OK	OK	-	-	-	OK	-	-
HDR-TD30V	-	OK	OK	OK	OK	OK	-	-	-	OK	-	-
HDR-CX190	-	OK	OK	OK	OK	OK	-	-	-	OK	-	-
HDR-CX200	-	OK	OK	OK	OK	OK	-	-	-	OK	-	-
HDR-CX210	-	OK	OK	OK	OK	OK	-	-	-	OK	-	-
HDR-CX260V	-	OK	OK	OK	OK	OK	-	-	-	OK	-	-
HDR-CX580V	-	OK	OK	OK	OK	OK	-	-	-	OK	-	-
HDR-CX760V	-	OK	OK	OK	OK	OK	-	-	-	OK	-	-
HDR-GW77V	-	-	-	-	-	-	-	-	-	-	-	-
HDR-PJ200	-	OK	OK	OK	OK	OK	-	-	-	OK	-	-
HDR-PJ260V	-	OK	OK	OK	OK	OK	-	-	-	OK	-	-
HDR-PJ580V	-	OK	OK	OK	OK	OK	-	-	-	OK	-	-
HDR-PJ710V	-	OK	OK	OK	OK	OK	-	-	-	OK	-	-
HDR-PJ760V	-	OK	OK	OK	OK	OK	-	-	-	OK	-	-
HDR-TD20V	-	OK	OK	OK	OK	OK	-	-	-	OK	-	-

	SD Memory Card											
Camcorder	**SF-4BF**	**SF-4C4**	**SF-4N4**	**SF-4N4D**	**SF-4U4**	**SF-4U6**	**SF-64BF**	**SF-64C4**	**SF-64N4**	**SF-64UX**	**SF-64UX2**	**SF-64UY**
HDR-XR260V	-	OK	OK	OK	OK	OK	-	-	-	OK	-	-
DCR-SX45	-	OK	OK	OK	OK	OK	-	-	-	OK	-	-
DCR-SX65	-	OK	OK	OK	OK	OK	-	-	-	OK	-	-
DCR-SX85	-	OK	OK	OK	OK	OK	-	-	-	OK	-	-
HDR-CX130	-	OK	OK	OK	OK	OK	-	-	-	OK	-	-
HDR-CX160	-	OK	OK	OK	OK	OK	-	-	-	OK	-	-
HDR-CX360V	-	OK	OK	OK	OK	OK	-	-	-	OK	-	-
HDR-CX560V	-	OK	OK	OK	OK	OK	-	-	-	OK	-	-
HDR-CX700V	-	OK	OK	OK	OK	OK	-	-	-	OK	-	-
HDR-PJ10	-	OK	OK	OK	OK	OK	-	-	-	OK	-	-
HDR-PJ30V	-	OK	OK	OK	OK	OK	-	-	-	OK	-	-
HDR-PJ50V	-	OK	OK	OK	OK	OK	-	-	-	OK	-	-
HDR-TD10	-	OK	OK	OK	OK	OK	-	-	-	OK	-	-
HDR-XR160	-	OK	OK	OK	OK	OK	-	-	-	OK	-	-
DCR-SR68	-	OK	OK	OK	OK	OK	-	-	-	OK	-	-
DCR-SR88	-	OK	OK	OK	OK	OK	-	-	-	OK	-	-
DCR-SX43	-	OK	OK	OK	OK	OK	-	-	-	OK	-	-

	SD Memory Card											
Camcorder	**SF-4BF**	**SF-4C4**	**SF-4N4**	**SF-4N4D**	**SF-4U4**	**SF-4U6**	**SF-64BF**	**SF-64C4**	**SF-64N4**	**SF-64UX**	**SF-64UX2**	**SF-64UY**
DCR-SX44	-	OK	OK	OK	OK	OK	-	-	-	OK	-	-
DCR-SX63	-	OK	OK	OK	OK	OK	-	-	-	OK	-	-
DCR-SX83	-	OK	OK	OK	OK	OK	-	-	-	OK	-	-
HDR-AX2000	-	OK	OK	OK	OK	OK	-	-	-	OK	-	-
HDR-CX110	-	OK	OK	OK	OK	OK	-	-	-	OK	-	-
HDR-CX150	-	OK	OK	OK	OK	OK	-	-	-	OK	-	-
HDR-CX300	-	OK	OK	OK	OK	OK	-	-	-	OK	-	-
HDR-CX350V	-	OK	OK	OK	OK	OK	-	-	-	OK	-	-
HDR-CX550V	-	OK	OK	OK	OK	OK	-	-	-	OK	-	-
HDR-XR150	-	OK	OK	OK	OK	OK	-	-	-	OK	-	-
HDR-XR350V	-	OK	OK	OK	OK	OK	-	-	-	OK	-	-
HDR-XR550V	-	OK	OK	OK	OK	OK	-	-	-	OK	-	-
NEX-VG30	-	OK	OK	OK	OK	OK	-	-	-	OK	-	-
NEX-VG30H	-	OK	OK	OK	OK	OK	-	-	-	OK	-	-
NEX-VG900	-	OK	OK	OK	OK	OK	-	-	-	OK	-	-
NEX-VG20	-	OK	OK	OK	OK	OK	-	-	-	OK	-	-
NEX-VG20H	-	OK	OK	OK	OK	OK	-	-	-	OK	-	-

	SD Memory Card											
Camcorder	**SF-4BF**	**SF-4C4**	**SF-4N4**	**SF-4N4D**	**SF-4U4**	**SF-4U6**	**SF-64BF**	**SF-64C4**	**SF-64N4**	**SF-64UX**	**SF-64UX2**	**SF-64UY**
NEX-VG10	-	OK	OK	OK	OK	OK	-	-	-	OK	-	-
HDR-AS20	-	-	-	-	-	-	-	-	-	-	-	-
HDR-AS100V	-	-	-	-	-	-	-	-	-	-	-	-
HDR-AS100VB	-	-	-	-	-	-	-	-	-	-	-	-
HDR-AS100VR	-	-	-	-	-	-	-	-	-	-	-	-
HDR-AS100VW	-	-	-	-	-	-	-	-	-	-	-	-
HDR-AS30V	-	-	-	-	-	-	-	-	-	-	-	-
HDR-AS30VB	-	-	-	-	-	-	-	-	-	-	-	-
HDR-AS30VD	-	-	-	-	-	-	-	-	-	-	-	-
HDR-AS30VR	-	-	-	-	-	-	-	-	-	-	-	-
HDR-AS30VW	-	-	-	-	-	-	-	-	-	-	-	-

	SD Memory Card											
Camcorder	**SF-64UZ**	**SF-8B4**	**SF-8BF**	**SF-8C4**	**SF-8N4**	**SF-8NX**	**SF-8U4**	**SF-8U6**	**SF-8UX**	**SF-8UY**	**SF-G1UX2**	**SF-G1UY**
FDR-AX100	-	OK *53	OK *53	OK *53	OK *53	OK *53	OK *53	OK *53	OK	OK *53	-	-
HDR-CX240	-	-	-	-	-	-	-	-	-	-	-	-
HDR-CX330	-	-	-	-	-	-	-	-	-	-	-	-
HDR-CX900	-	OK *53	OK *53	OK *53	OK *53	OK *53	OK *53	OK *53	OK	OK *53	-	-
HDR-PJ275	-	-	-	-	-	-	-	-	-	-	-	-
HDR-PJ340	-	-	-	-	-	-	-	-	-	-	-	-
HDR-PJ350	-	-	-	-	-	-	-	-	-	-	-	-
HDR-PJ540	-	-	-	-	-	-	-	-	-	-	-	-
HDR-PJ810	-	OK	OK	OK	OK	OK	OK	OK	OK	OK	-	-
HDR-CX220	-	OK	-	OK	OK	OK	OK	OK	OK	OK	-	-
HDR-CX230	-	OK	-	OK	OK	OK	OK	OK	OK	OK	-	-
HDR-CX290	-	OK	-	OK	OK	OK	OK	OK	OK	OK	-	-
HDR-CX380	-	OK	-	OK	OK	OK	OK	OK	OK	OK	-	-
HDR-CX430V	-	OK	-	OK	OK	OK	OK	OK	OK	OK	-	-
HDR-PJ230	-	OK	-	OK	OK	OK	OK	OK	OK	OK	-	-
HDR-PJ380	-	OK	-	OK	OK	OK	OK	OK	OK	OK	-	-

	SD Memory Card											
Camcorder	**SF-64UZ**	**SF-8B4**	**SF-8BF**	**SF-8C4**	**SF-8N4**	**SF-8NX**	**SF-8U4**	**SF-8U6**	**SF-8UX**	**SF-8UY**	**SF-G1UX2**	**SF-G1UY**
HDR-PJ430V	-	OK	-	OK	OK	OK	OK	OK	OK	OK	-	-
HDR-PJ650V	-	OK	-	OK	OK	OK	OK	OK	OK	OK	-	-
HDR-PJ790V	-	OK	-	OK	OK	OK	OK	OK	OK	OK	-	-
HDR-TD30V	-	OK	-	OK	OK	OK	OK	OK	OK	OK	-	-
HDR-CX190	-	OK	-	OK	OK	OK	OK	OK	OK	OK	-	-
HDR-CX200	-	OK	-	OK	OK	OK	OK	OK	OK	OK	-	-
HDR-CX210	-	OK	-	OK	OK	OK	OK	OK	OK	OK	-	-
HDR-CX260V	-	OK	-	OK	OK	OK	OK	OK	OK	OK	-	-
HDR-CX580V	-	OK	-	OK	OK	OK	OK	OK	OK	OK	-	-
HDR-CX760V	-	OK	-	OK	OK	OK	OK	OK	OK	OK	-	-
HDR-GW77V	-	-	-	-	-	-	-	-	-	-	-	-
HDR-PJ200	-	OK	-	OK	OK	OK	OK	OK	OK	OK	-	-
HDR-PJ260V	-	OK	-	OK	OK	OK	OK	OK	OK	OK	-	-
HDR-PJ580V	-	OK	-	OK	OK	OK	OK	OK	OK	OK	-	-
HDR-PJ710V	-	OK	-	OK	OK	OK	OK	OK	OK	OK	-	-
HDR-PJ760V	-	OK	-	OK	OK	OK	OK	OK	OK	OK	-	-
HDR-TD20V	-	OK	-	OK	OK	OK	OK	OK	OK	OK	-	-

	SD Memory Card											
Camcorder	**SF-64UZ**	**SF-8B4**	**SF-8BF**	**SF-8C4**	**SF-8N4**	**SF-8NX**	**SF-8U4**	**SF-8U6**	**SF-8UX**	**SF-8UY**	**SF-G1UX2**	**SF-G1UY**
HDR-XR260V	-	OK	-	OK	OK	OK	OK	OK	OK	OK	-	-
DCR-SX45	-	OK	-	OK	OK	OK	OK	OK	OK	OK	-	-
DCR-SX65	-	OK	-	OK	OK	OK	OK	OK	OK	OK	-	-
DCR-SX85	-	OK	-	OK	OK	OK	OK	OK	OK	OK	-	-
HDR-CX130	-	OK	-	OK	OK	OK	OK	OK	OK	OK	-	-
HDR-CX160	-	OK	-	OK	OK	OK	OK	OK	OK	OK	-	-
HDR-CX360V	-	OK	-	OK	OK	OK	OK	OK	OK	OK	-	-
HDR-CX560V	-	OK	-	OK	OK	OK	OK	OK	OK	OK	-	-
HDR-CX700V	-	OK	-	OK	OK	OK	OK	OK	OK	OK	-	-
HDR-PJ10	-	OK	-	OK	OK	OK	OK	OK	OK	OK	-	-
HDR-PJ30V	-	OK	-	OK	OK	OK	OK	OK	OK	OK	-	-
HDR-PJ50V	-	OK	-	OK	OK	OK	OK	OK	OK	OK	-	-
HDR-TD10	-	OK	-	OK	OK	OK	OK	OK	OK	OK	-	-
HDR-XR160	-	OK	-	OK	OK	OK	OK	OK	OK	OK	-	-
DCR-SR68	-	OK	-	OK	OK	OK	OK	OK	OK	OK	-	-
DCR-SR88	-	OK	-	OK	OK	OK	OK	OK	OK	OK	-	-
DCR-SX43	-	OK	-	OK	OK	OK	OK	OK	OK	OK	-	-

	SD Memory Card											
Camcorder	**SF-64UZ**	**SF-8B4**	**SF-8BF**	**SF-8C4**	**SF-8N4**	**SF-8NX**	**SF-8U4**	**SF-8U6**	**SF-8UX**	**SF-8UY**	**SF-G1UX2**	**SF-G1UY**
DCR-SX44	-	OK	-	OK	OK	OK	OK	OK	OK	OK	-	-
DCR-SX63	-	OK	-	OK	OK	OK	OK	OK	OK	OK	-	-
DCR-SX83	-	OK	-	OK	OK	OK	OK	OK	OK	OK	-	-
HDR-AX2000	-	OK	-	OK	OK	OK	OK	OK	OK	OK	-	-
HDR-CX110	-	OK	-	OK	OK	OK	OK	OK	OK	OK	-	-
HDR-CX150	-	OK	-	OK	OK	OK	OK	OK	OK	OK	-	-
HDR-CX300	-	OK	-	OK	OK	OK	OK	OK	OK	OK	-	-
HDR-CX350V	-	OK	-	OK	OK	OK	OK	OK	OK	OK	-	-
HDR-CX550V	-	OK	-	OK	OK	OK	OK	OK	OK	OK	-	-
HDR-XR150	-	OK	-	OK	OK	OK	OK	OK	OK	OK	-	-
HDR-XR350V	-	OK	-	OK	OK	OK	OK	OK	OK	OK	-	-
HDR-XR550V	-	OK	-	OK	OK	OK	OK	OK	OK	OK	-	-
NEX-VG30	-	OK	-	OK	OK	OK	OK	OK	OK	OK	-	-
NEX-VG30H	-	OK	-	OK	OK	OK	OK	OK	OK	OK	-	-
NEX-VG900	-	OK	-	OK	OK	OK	OK	OK	OK	OK	-	-
NEX-VG20	-	OK	-	OK	OK	OK	OK	OK	OK	OK	-	-
NEX-VG20H	-	OK	-	OK	OK	OK	OK	OK	OK	OK	-	-

	SD Memory Card											
Camcorder	**SF-64UZ**	**SF-8B4**	**SF-8BF**	**SF-8C4**	**SF-8N4**	**SF-8NX**	**SF-8U4**	**SF-8U6**	**SF-8UX**	**SF-8UY**	**SF-G1UX2**	**SF-G1UY**
NEX-VG10	-	OK	-	OK	OK	OK	OK	OK	OK	OK	-	-
HDR-AS20	-	-	-	-	-	-	-	-	-	-	-	-
HDR-AS100V	-	-	-	-	-	-	-	-	-	-	-	-
HDR-AS100VB	-	-	-	-	-	-	-	-	-	-	-	-
HDR-AS100VR	-	-	-	-	-	-	-	-	-	-	-	-
HDR-AS100VW	-	-	-	-	-	-	-	-	-	-	-	-
HDR-AS30V	-	-	-	-	-	-	-	-	-	-	-	-
HDR-AS30VB	-	-	-	-	-	-	-	-	-	-	-	-
HDR-AS30VD	-	-	-	-	-	-	-	-	-	-	-	-
HDR-AS30VR	-	-	-	-	-	-	-	-	-	-	-	-
HDR-AS30VW	-	-	-	-	-	-	-	-	-	-	-	-

Camcorder	SD Memory Card											
	SR-16A4	SR-16C4	SR-16UX	SR-16UXA	SR-16UY	SR-16UYA	SR-2A1	SR-2C1	SR-2N1	SR-32A4	SR-32C4	SR-32UX
FDR-AX100	OK *46 *53	OK *46 *53	OK	OK *46 *53	OK *53	OK *46 *53	OK *46 *53	OK *46 *53	-	OK *46 *53	OK *46 *53	OK
HDR-CX240	OK	OK	-	-	OK	OK	-	-	-	OK	OK	-
HDR-CX330	OK	OK	-	-	OK	OK	-	-	-	OK	OK	-
HDR-CX900	OK *46 *53	OK *46 *53	OK	OK *46 *53	OK *53	OK *46 *53	OK *46 *53	OK *46 *53	-	OK *46 *53	OK *46 *53	OK
HDR-PJ275	OK	OK	-	-	OK	OK	-	-	-	OK	OK	-
HDR-PJ340	OK	OK	-	-	OK	OK	-	-	-	OK	OK	-
HDR-PJ350	OK	OK	-	-	OK	OK	-	-	-	OK	OK	-
HDR-PJ540	OK	OK	-	OK	OK	OK	-	-	-	OK	OK	-
HDR-PJ810	OK *46	OK *46	OK	OK *46	OK *46	OK *46	-	-	-	OK *46	OK *46	OK
HDR-CX220	OK *46	OK *46	-	-	OK *46	OK *46	-	-	-	OK *46	OK *46	-
HDR-CX230	OK *46	OK *46	-	-	OK *46	OK *46	-	-	-	OK *46	OK *46	-
HDR-CX290	OK *46	OK *46	-	-	OK *46	OK *46	-	-	-	OK *46	OK *46	-
HDR-CX380	OK *46	OK *46	-	-	OK *46	OK *46	-	-	-	OK *46	OK *46	-
HDR-CX430V	OK *46	OK *46	-	-	OK *46	OK *46	-	-	-	OK *46	OK *46	-
HDR-PJ230	OK *46	OK *46	-	-	OK *46	OK *46	-	-	-	OK *46	OK *46	-
HDR-PJ380	OK *46	OK *46	-	-	OK *46	OK *46	-	-	-	OK *46	OK *46	-

	SD Memory Card											
Camcorder	**SR-16A4**	**SR-16C4**	**SR-16UX**	**SR-16UXA**	**SR-16UY**	**SR-16UYA**	**SR-2A1**	**SR-2C1**	**SR-2N1**	**SR-32A4**	**SR-32C4**	**SR-32UX**
HDR-PJ430V	OK *46	OK *46	-	-	OK *46	OK *46	-	-	-	OK *46	OK *46	-
HDR-PJ650V	OK *46	OK *46	-	-	OK *46	OK *46	-	-	-	OK *46	OK *46	-
HDR-PJ790V	OK *46	OK *46	-	-	OK *46	OK *46	-	-	-	OK *46	OK *46	-
HDR-TD30V	OK *46	OK *46	-	-	OK *46	OK *46	-	-	-	OK *46	OK *46	-
HDR-CX190	OK *46	OK *46	-	-	OK *46	OK *46	-	-	-	OK *46	OK *46	-
HDR-CX200	OK *46	OK *46	-	-	OK *46	OK *46	-	-	-	OK *46	OK *46	-
HDR-CX210	OK *46	OK *46	-	-	OK *46	OK *46	-	-	-	OK *46	OK *46	-
HDR-CX260V	OK *46	OK *46	-	-	OK *46	OK *46	-	-	-	OK *46	OK *46	-
HDR-CX580V	OK *46	OK *46	-	-	OK *46	OK *46	-	-	-	OK *46	OK *46	-
HDR-CX760V	OK *46	OK *46	-	-	OK *46	OK *46	-	-	-	OK *46	OK *46	-
HDR-GW77V	OK	OK	-	-	OK	OK	-	-	-	OK	OK	-
HDR-PJ200	OK *46	OK *46	-	-	OK *46	OK *46	-	-	-	OK *46	OK *46	-
HDR-PJ260V	OK *46	OK *46	-	-	OK *46	OK *46	-	-	-	OK *46	OK *46	-
HDR-PJ580V	OK *46	OK *46	-	-	OK *46	OK *46	-	-	-	OK *46	OK *46	-
HDR-PJ710V	OK *46	OK *46	-	-	OK *46	OK *46	-	-	-	OK *46	OK *46	-
HDR-PJ760V	OK *46	OK *46	-	-	OK *46	OK *46	-	-	-	OK *46	OK *46	-
HDR-TD20V	OK *46	OK *46	-	-	OK *46	OK *46	-	-	-	OK *46	OK *46	-

	SD Memory Card											
Camcorder	**SR-16A4**	**SR-16C4**	**SR-16UX**	**SR-16UXA**	**SR-16UY**	**SR-16UYA**	**SR-2A1**	**SR-2C1**	**SR-2N1**	**SR-32A4**	**SR-32C4**	**SR-32UX**
HDR-XR260V	OK *46	OK *46	-	-	OK *46	OK *46	-	-	-	OK *46	OK *46	-
DCR-SX45	-	-	-	-	-	-	-	-	-	-	-	-
DCR-SX65	-	-	-	-	-	-	-	-	-	-	-	-
DCR-SX85	-	-	-	-	-	-	-	-	-	-	-	-
HDR-CX130	-	-	-	-	-	-	-	-	-	-	-	-
HDR-CX160	-	-	-	-	-	-	-	-	-	-	-	-
HDR-CX360V	-	-	-	-	-	-	-	-	-	-	-	-
HDR-CX560V	-	-	-	-	-	-	-	-	-	-	-	-
HDR-CX700V	-	-	-	-	-	-	-	-	-	-	-	-
HDR-PJ10	-	-	-	-	-	-	-	-	-	-	-	-
HDR-PJ30V	-	-	-	-	-	-	-	-	-	-	-	-
HDR-PJ50V	-	-	-	-	-	-	-	-	-	-	-	-
HDR-TD10	-	-	-	-	-	-	-	-	-	-	-	-
HDR-XR160	-	-	-	-	-	-	-	-	-	-	-	-
DCR-SR68	-	-	-	-	-	-	-	-	-	-	-	-
DCR-SR88	-	-	-	-	-	-	-	-	-	-	-	-
DCR-SX43	-	-	-	-	-	-	-	-	-	-	-	-

Camcorder	SD Memory Card											
	SR-16A4	SR-16C4	SR-16UX	SR-16UXA	SR-16UY	SR-16UYA	SR-2A1	SR-2C1	SR-2N1	SR-32A4	SR-32C4	SR-32UX
DCR-SX44	-	-	-	-	-	-	-	-	-	-	-	-
DCR-SX63	-	-	-	-	-	-	-	-	-	-	-	-
DCR-SX83	-	-	-	-	-	-	-	-	-	-	-	-
HDR-AX2000	-	-	-	-	-	-	-	-	-	-	-	-
HDR-CX110	-	-	-	-	-	-	-	-	-	-	-	-
HDR-CX150	-	-	-	-	-	-	-	-	-	-	-	-
HDR-CX300	-	-	-	-	-	-	-	-	-	-	-	-
HDR-CX350V	-	-	-	-	-	-	-	-	-	-	-	-
HDR-CX550V	-	-	-	-	-	-	-	-	-	-	-	-
HDR-XR150	-	-	-	-	-	-	-	-	-	-	-	-
HDR-XR350V	-	-	-	-	-	-	-	-	-	-	-	-
HDR-XR550V	-	-	-	-	-	-	-	-	-	-	-	-
NEX-VG30	-	-	-	-	-	-	-	-	-	-	-	-
NEX-VG30H	-	-	-	-	-	-	-	-	-	-	-	-
NEX-VG900	-	-	-	-	-	-	-	-	-	-	-	-
NEX-VG20	-	-	-	-	-	-	-	-	-	-	-	-
NEX-VG20H	-	-	-	-	-	-	-	-	-	-	-	-

	SD Memory Card											
Camcorder	**SR-16A4**	**SR-16C4**	**SR-16UX**	**SR-16UXA**	**SR-16UY**	**SR-16UYA**	**SR-2A1**	**SR-2C1**	**SR-2N1**	**SR-32A4**	**SR-32C4**	**SR-32UX**
NEX-VG10	-	-	-	-	-	-	-	-	-	-	-	-
HDR-AS20	OK	OK	-	TBD	OK	OK	-	-	TBD	OK	OK	-
HDR-AS100V	OK *53	OK *53	-	TBD	OK *53	OK *53	-	-	TBD	OK *53	OK *53	-
HDR-AS100VB	OK *53	OK *53	-	TBD	OK *53	OK *53	-	-	TBD	OK *53	OK *53	-
HDR-AS100VR	OK *53	OK *53	-	TBD	OK *53	OK *53	-	-	TBD	OK *53	OK *53	-
HDR-AS100VW	OK *53	OK *53	-	TBD	OK *53	OK *53	-	-	TBD	OK *53	OK *53	-
HDR-AS30V	OK	OK	-	-	OK	OK	-	-	-	OK	OK	-
HDR-AS30VB	OK	OK	-	-	OK	OK	-	-	-	OK	OK	-
HDR-AS30VD	OK	OK	-	-	OK	OK	-	-	-	OK	OK	-
HDR-AS30VR	OK	OK	-	-	OK	OK	-	-	-	OK	OK	-
HDR-AS30VW	OK	OK	-	-	OK	OK	-	-	-	OK	OK	-

	SD Memory Card											
Camcorder	**SR-32UXA**	**SR-32UY**	**SR-32UYA**	**SR-4A4**	**SR-4C4**	**SR-4N2**	**SR-64UX**	**SR-64UXA**	**SR-64UY**	**SR-64UYA**	**SR-8A4**	**SR-8A4D**
FDR-AX100	OK *46 *53	OK *53	OK *46 *53	OK *46 *53	OK *46 *53	-	OK	OK *46 *53	OK	OK *46 *53	OK *46 *53	OK *46 *53
HDR-CX240	-	OK	OK	OK	OK	-	-	-	-	OK	OK	OK
HDR-CX330	-	OK	OK	OK	OK	-	-	-	-	OK	OK	OK
HDR-CX900	OK *46 *53	OK *53	OK *46 *53	OK *46 *53	OK *46 *53	-	OK	OK *46 *53	OK	OK *46 *53	OK *46 *53	OK *46 *53
HDR-PJ275	-	OK	OK	OK	OK	-	-	-	-	OK	OK	OK
HDR-PJ340	-	OK	OK	OK	OK	-	-	-	-	OK	OK	OK
HDR-PJ350	-	OK	OK	OK	OK	-	-	-	-	OK	OK	OK
HDR-PJ540	OK	OK	OK	OK	OK	-	-	OK	-	OK	OK	OK
HDR-PJ810	OK *46	OK *46	OK *46	OK *46	OK *46	-	OK	OK *46	-	OK *46	OK *46	OK *46
HDR-CX220	-	OK *46	OK *46	OK *46	OK *46	-	-	-	-	-	OK *46	-
HDR-CX230	-	OK *46	OK *46	OK *46	OK *46	-	-	-	-	-	OK *46	-
HDR-CX290	-	OK *46	OK *46	OK *46	OK *46	-	-	-	-	-	OK *46	-
HDR-CX380	-	OK *46	OK *46	OK *46	OK *46	-	-	-	-	-	OK *46	-
HDR-CX430V	-	OK *46	OK *46	OK *46	OK *46	-	-	-	-	-	OK *46	-
HDR-PJ230	-	OK *46	OK *46	OK *46	OK *46	-	-	-	-	-	OK *46	-
HDR-PJ380	-	OK *46	OK *46	OK *46	OK *46	-	-	-	-	-	OK *46	-

	SD Memory Card											
Camcorder	**SR-32UXA**	**SR-32UY**	**SR-32UYA**	**SR-4A4**	**SR-4C4**	**SR-4N2**	**SR-64UX**	**SR-64UXA**	**SR-64UY**	**SR-64UYA**	**SR-8A4**	**SR-8A4D**
HDR-PJ430V	-	OK *46	OK *46	OK *46	OK *46	-	-	-	-	-	OK *46	-
HDR-PJ650V	-	OK *46	OK *46	OK *46	OK *46	-	-	-	-	-	OK *46	-
HDR-PJ790V	-	OK *46	OK *46	OK *46	OK *46	-	-	-	-	-	OK *46	-
HDR-TD30V	-	OK *46	OK *46	OK *46	OK *46	-	-	-	-	-	OK *46	-
HDR-CX190	-	OK *46	OK *46	OK *46	OK *46	-	-	-	-	-	OK *46	-
HDR-CX200	-	OK *46	OK *46	OK *46	OK *46	-	-	-	-	-	OK *46	-
HDR-CX210	-	OK *46	OK *46	OK *46	OK *46	-	-	-	-	-	OK *46	-
HDR-CX260V	-	OK *46	OK *46	OK *46	OK *46	-	-	-	-	-	OK *46	-
HDR-CX580V	-	OK *46	OK *46	OK *46	OK *46	-	-	-	-	-	OK *46	-
HDR-CX760V	-	OK *46	OK *46	OK *46	OK *46	-	-	-	-	-	OK *46	-
HDR-GW77V	-	OK	OK	OK	OK	-	-	-	-	-	OK	-
HDR-PJ200	-	OK *46	OK *46	OK *46	OK *46	-	-	-	-	-	OK *46	-
HDR-PJ260V	-	OK *46	OK *46	OK *46	OK *46	-	-	-	-	-	OK *46	-
HDR-PJ580V	-	OK *46	OK *46	OK *46	OK *46	-	-	-	-	-	OK *46	-
HDR-PJ710V	-	OK *46	OK *46	OK *46	OK *46	-	-	-	-	-	OK *46	-
HDR-PJ760V	-	OK *46	OK *46	OK *46	OK *46	-	-	-	-	-	OK *46	-
HDR-TD20V	-	OK *46	OK *46	OK *46	OK *46	-	-	-	-	-	OK *46	-

	SD Memory Card											
Camcorder	**SR-32UXA**	**SR-32UY**	**SR-32UYA**	**SR-4A4**	**SR-4C4**	**SR-4N2**	**SR-64UX**	**SR-64UXA**	**SR-64UY**	**SR-64UYA**	**SR-8A4**	**SR-8A4D**
HDR-XR260V	-	OK *46	OK *46	OK *46	OK *46	-	-	-	-	-	OK *46	-
DCR-SX45	-	-	-	-	-	-	-	-	-	-	-	-
DCR-SX65	-	-	-	-	-	-	-	-	-	-	-	-
DCR-SX85	-	-	-	-	-	-	-	-	-	-	-	-
HDR-CX130	-	-	-	-	-	-	-	-	-	-	-	-
HDR-CX160	-	-	-	-	-	-	-	-	-	-	-	-
HDR-CX360V	-	-	-	-	-	-	-	-	-	-	-	-
HDR-CX560V	-	-	-	-	-	-	-	-	-	-	-	-
HDR-CX700V	-	-	-	-	-	-	-	-	-	-	-	-
HDR-PJ10	-	-	-	-	-	-	-	-	-	-	-	-
HDR-PJ30V	-	-	-	-	-	-	-	-	-	-	-	-
HDR-PJ50V	-	-	-	-	-	-	-	-	-	-	-	-
HDR-TD10	-	-	-	-	-	-	-	-	-	-	-	-
HDR-XR160	-	-	-	-	-	-	-	-	-	-	-	-
DCR-SR68	-	-	-	-	-	-	-	-	-	-	-	-
DCR-SR88	-	-	-	-	-	-	-	-	-	-	-	-
DCR-SX43	-	-	-	-	-	-	-	-	-	-	-	-

	SD Memory Card											
Camcorder	SR-32UXA	SR-32UY	SR-32UYA	SR-4A4	SR-4C4	SR-4N2	SR-64UX	SR-64UXA	SR-64UY	SR-64UYA	SR-8A4	SR-8A4D
DCR-SX44	-	-	-	-	-	-	-	-	-	-	-	-
DCR-SX63	-	-	-	-	-	-	-	-	-	-	-	-
DCR-SX83	-	-	-	-	-	-	-	-	-	-	-	-
HDR-AX2000	-	-	-	-	-	-	-	-	-	-	-	-
HDR-CX110	-	-	-	-	-	-	-	-	-	-	-	-
HDR-CX150	-	-	-	-	-	-	-	-	-	-	-	-
HDR-CX300	-	-	-	-	-	-	-	-	-	-	-	-
HDR-CX350V	-	-	-	-	-	-	-	-	-	-	-	-
HDR-CX550V	-	-	-	-	-	-	-	-	-	-	-	-
HDR-XR150	-	-	-	-	-	-	-	-	-	-	-	-
HDR-XR350V	-	-	-	-	-	-	-	-	-	-	-	-
HDR-XR550V	-	-	-	-	-	-	-	-	-	-	-	-
NEX-VG30	-	-	-	-	-	-	-	-	-	-	-	-
NEX-VG30H	-	-	-	-	-	-	-	-	-	-	-	-
NEX-VG900	-	-	-	-	-	-	-	-	-	-	-	-
NEX-VG20	-	-	-	-	-	-	-	-	-	-	-	-
NEX-VG20H	-	-	-	-	-	-	-	-	-	-	-	-

	SD Memory Card											
Camcorder	**SR-32UXA**	**SR-32UY**	**SR-32UYA**	**SR-4A4**	**SR-4C4**	**SR-4N2**	**SR-64UX**	**SR-64UXA**	**SR-64UY**	**SR-64UYA**	**SR-8A4**	**SR-8A4D**
NEX-VG10	-	-	-	-	-	-	-	-	-	-	-	-
HDR-AS20	TBD	OK	OK	OK	OK	TBD	-	TBD	TBD	OK	OK	TBD
HDR-AS100V	TBD	OK *53	OK *53	OK *53	OK *53	TBD	-	TBD	TBD	OK	OK *53	TBD
HDR-AS100VB	TBD	OK *53	OK *53	OK *53	OK *53	TBD	-	TBD	TBD	OK	OK *53	TBD
HDR-AS100VR	TBD	OK *53	OK *53	OK *53	OK *53	TBD	-	TBD	TBD	OK	OK *53	TBD
HDR-AS100VW	TBD	OK *53	OK *53	OK *53	OK *53	TBD	-	TBD	TBD	OK	OK *53	TBD
HDR-AS30V	-	OK	OK	OK	OK	-	-	-	-	OK	OK	-
HDR-AS30VB	-	OK	OK	OK	OK	-	-	-	-	OK	OK	-
HDR-AS30VD	-	OK	OK	OK	OK	-	-	-	-	OK	OK	-
HDR-AS30VR	-	OK	OK	OK	OK	-	-	-	-	OK	OK	-
HDR-AS30VW	-	OK	OK	OK	OK	-	-	-	-	OK	OK	-

	SD Memory Card				
Camcorder	**SR-8C4**	**SR-8N2**	**SR-8UY**	**SR-8UYA**	**SRAC-A1**
FDR-AX100	OK *46 *53	-	OK *53	OK *46 *53	OK *46 *53
HDR-CX240	OK	-	OK	OK	-
HDR-CX330	OK	-	OK	OK	-
HDR-CX900	OK *46 *53	-	OK *53	OK *46 *53	OK *46 *53
HDR-PJ275	OK	-	OK	OK	-
HDR-PJ340	OK	-	OK	OK	-
HDR-PJ350	OK	-	OK	OK	-
HDR-PJ540	OK	-	OK	OK	-
HDR-PJ810	OK *46	-	OK *46	OK *46	-
HDR-CX220	OK *46	-	OK *46	OK *46	-
HDR-CX230	OK *46	-	OK *46	OK *46	-
HDR-CX290	OK *46	-	OK *46	OK *46	-
HDR-CX380	OK *46	-	OK *46	OK *46	-
HDR-CX430V	OK *46	-	OK *46	OK *46	-
HDR-PJ230	OK *46	-	OK *46	OK *46	-
HDR-PJ380	OK *46	-	OK *46	OK *46	-

	SD Memory Card				
Camcorder	**SR-8C4**	**SR-8N2**	**SR-8UY**	**SR-8UYA**	**SRAC-A1**
HDR-PJ430V	OK *46	-	OK *46	OK *46	-
HDR-PJ650V	OK *46	-	OK *46	OK *46	-
HDR-PJ790V	OK *46	-	OK *46	OK *46	-
HDR-TD30V	OK *46	-	OK *46	OK *46	-
HDR-CX190	OK *46	-	OK *46	OK *46	-
HDR-CX200	OK *46	-	OK *46	OK *46	-
HDR-CX210	OK *46	-	OK *46	OK *46	-
HDR-CX260V	OK *46	-	OK *46	OK *46	-
HDR-CX580V	OK *46	-	OK *46	OK *46	-
HDR-CX760V	OK *46	-	OK *46	OK *46	-
HDR-GW77V	OK	-	OK	OK	-
HDR-PJ200	OK *46	-	OK *46	OK *46	-
HDR-PJ260V	OK *46	-	OK *46	OK *46	-
HDR-PJ580V	OK *46	-	OK *46	OK *46	-
HDR-PJ710V	OK *46	-	OK *46	OK *46	-
HDR-PJ760V	OK *46	-	OK *46	OK *46	-
HDR-TD20V	OK *46	-	OK *46	OK *46	-

	SD Memory Card				
Camcorder	**SR-8C4**	**SR-8N2**	**SR-8UY**	**SR-8UYA**	**SRAC-A1**
HDR-XR260V	OK *46	-	OK *46	OK *46	-
DCR-SX45	-	-	-	-	-
DCR-SX65	-	-	-	-	-
DCR-SX85	-	-	-	-	-
HDR-CX130	-	-	-	-	-
HDR-CX160	-	-	-	-	-
HDR-CX360V	-	-	-	-	-
HDR-CX560V	-	-	-	-	-
HDR-CX700V	-	-	-	-	-
HDR-PJ10	-	-	-	-	-
HDR-PJ30V	-	-	-	-	-
HDR-PJ50V	-	-	-	-	-
HDR-TD10	-	-	-	-	-
HDR-XR160	-	-	-	-	-
DCR-SR68	-	-	-	-	-
DCR-SR88	-	-	-	-	-
DCR-SX43	-	-	-	-	-

	SD Memory Card				
Camcorder	SR-8C4	SR-8N2	SR-8UY	SR-8UYA	SRAC-A1
DCR-SX44	-	-	-	-	-
DCR-SX63	-	-	-	-	-
DCR-SX83	-	-	-	-	-
HDR-AX2000	-	-	-	-	-
HDR-CX110	-	-	-	-	-
HDR-CX150	-	-	-	-	-
HDR-CX300	-	-	-	-	-
HDR-CX350V	-	-	-	-	-
HDR-CX550V	-	-	-	-	-
HDR-XR150	-	-	-	-	-
HDR-XR350V	-	-	-	-	-
HDR-XR550V	-	-	-	-	-
NEX-VG30	-	-	-	-	-
NEX-VG30H	-	-	-	-	-
NEX-VG900	-	-	-	-	-
NEX-VG20	-	-	-	-	-
NEX-VG20H	-	-	-	-	-

	SD Memory Card				
Camcorder	**SR-8C4**	**SR-8N2**	**SR-8UY**	**SR-8UYA**	**SRAC-A1**
NEX-VG10	-	-	-	-	-
HDR-AS20	OK	TBD	OK	OK	-
HDR-AS100V	OK *53	TBD	OK *53	OK *53	-
HDR-AS100VB	OK *53	TBD	OK *53	OK *53	-
HDR-AS100VR	OK *53	TBD	OK *53	OK *53	-
HDR-AS100VW	OK *53	TBD	OK *53	OK *53	-
HDR-AS30V	OK	-	OK	OK	-
HDR-AS30VB	OK	-	OK	OK	-
HDR-AS30VD	OK	-	OK	OK	-
HDR-AS30VR	OK	-	OK	OK	-
HDR-AS30VW	OK	-	OK	OK	-